

# INTEGRATION OF MITSUBISHI VRF WITH RENEWAIRE DOAS OR ERV SYSTEMS

In order to comply with ASHRAE 62.1 outdoor air requirements, it is common to pair a [dedicated outdoor air system](#) (DOAS) or [energy recovery ventilator](#) (ERV) unit with a variable refrigerant flow (VRF) system. **This document describes how to integrate a RenewAire DOAS or ERV with Premium controls to the Mitsubishi VRF system using input/output (I/O) connections.**


In an alternate configuration, the Mitsubishi system may turn the ERV on and off. In this case, the only connection is the on/off command. That scenario is not covered by this document.

## OVERVIEW OF COMPONENTS

The RenewAire unit comes with a heat pump coil either integral to the unit (DOAS) or as a separate component of the ERV ([HE+DX Coil](#)). A third option would be to have the coils supplied by others. The RenewAire coils have been designed in [CORES](#) according to specifications put forth by Mitsubishi to meet the needs of the VRF system.

The RenewAire unit requires [Premium Series Integrated Programmable Controls \(IPC\)](#) for operation. RenewAire DOAS units will come with a discharge air temperature sensor (DAT). ERV units must supply the sensor separately (P/N: 131318). This sensor is required for control.

The Mitsubishi system may have one or two circuits with an option for hot gas reheat. Each circuit and/or coil requires its own linear expansion valve (LEV) kit, which are supplied through Mitsubishi. The DOAS units have room to mount the electric expansion valves (EEV) with the coil compartment, but the [HE+DX coils](#) do not. If using the latter, a separate box must be field-sourced. Contact [RenewAire Technical Sales Support](#) for additional information.



## CONTROL TYPE


In this scenario there are two types of control possible: Type 1, where the RenewAire system conveys the discharge air setpoint to the Mitsubishi system and the Mitsubishi system decides the capacity required to maintain the setpoint, and Type 2, where the RenewAire system decides the capacity and conveys that to the Mitsubishi system. **It is suggested that Type 1 control is used as that is favored by Mitsubishi.**

In order for the two systems to work, at minimum, the RenewAire system must send the following information:

- ♦ Unit On Command
- ♦ 0–10 VDC discharge air setpoint or capacity, depending upon type
- ♦ Whether the RenewAire system is in heating or cooling mode



Minimum required for Type 1 control




Minimum required for Type 2 control

## CONTROL TYPE (CONT.)


With Type 1 control, the 0–10 VDC signal is sent in the following manner as designated by Mitsubishi.

$$\text{Input Voltage} = 5.625 \times \text{SetP} + 40.775[\text{F}]$$



For Type 2 capacity control, the signal will correspond to 0–100% of capacity requested, which can be clipped with minimum and maximum output settings. For example, 3–9 VDC.

Other optional information is as shown here:



The alarm input from the RenewAire system may not be required because the system will automatically turn the Mitsubishi unit off if there is an alarm.

The standard RenewAire system allows two binary inputs so there may be a limitation in the information coming from the Mitsubishi system. For example, if it is desired to have two inputs for defrost, the alarm signal could then be wired with the fan enable outputs, which will in turn shut the RenewAire unit off in alarm. This will be discussed further later in this document.

## SEQUENCE OF OPERATIONS

When the RenewAire unit is turned on by the controller screen and BMS (if enabled), the OA and RA dampers will open, allowing the fan speed to be conveyed to the fans for operation. If the current switch for each fan does not detect operation, the unit will shut down on fan alarm. (It is possible to run the exhaust fan if the supply fan fails.)

Once running, the unit will determine which mode, heating or cooling, based on lockout temperatures. Stage(s) of compressor will engage based on settings and a tempering mode output will tell whether that is heating or cooling. A discharge temperature setpoint will output as a 0–10 VDC signal if Type 1 control is used, or a 0–10 VDC capacity signal if Type 2 control is used.


One or two digital inputs (depending on number of stages) may indicate the stage is in defrost. When in defrost, the fans will turn off. The staging outputs for any stage in defrost will stay active and any that are not in defrost will be inactive.

If either system is in alarm, neither system shall run.

## WIRING

In this section we will explain the field wiring and show the purpose of each connection. See the [Wiring Diagrams](#) section at the end of this document for complete wiring diagrams.


This document includes wiring for the RenewAir units with the colored DIN terminals as shown. For wiring to the older style grey terminal blocks, [contact RenewAir](#).



**Wiring using colored DIN terminal blocks**  
In most cases, wiring will be direct to the controllers

## WIRING THE CONDITIONED AIR SENSOR


With DN units, the conditioned air sensor may already be wired into the unit. For ERV units, the sensor should be wired as follows.



**Wiring directly to the expansion module terminals**

## WIRING THE 0–10 VDC SIGNAL


The wiring for the 0–10 VDC signal does not change based on whether Type 1 or Type 2 control is used. The RenewAir unit uses the cooling command output U9 on the expansion module and wires to the B1 and B2 analog input on each staging LEV kit. (Hot gas reheat uses a separate output.)



**Wiring directly to the expansion module terminals**

## WIRING THE TEMPERING MODE

The tempering mode output from the RenewAir unit is a single dry contact output. Tempering mode is wired to the relay that in turn tells whether the unit is heating or cooling. The standard open output from RenewAir is open = heating, closed = cooling. An external relay is required. As shown in the picture, W1 should be closed for heating mode, Y1 should be closed for cooling mode. The Y1 output is also used for the HGRH enable, if used.



Mode input for each LEV kit—direct to expansion module

## THERMOSTAT CONNECTIONS AND INTERFACE DEVICE


Connector	Purpose	Purpose
TC	Common (In)	To Transformer
C	Common (Out)	To Thermostat
TR	24VAC (In)	To Transformer
R	24VAC (Out)	To Thermostat
G3	Fan High	High Fan Speed
G2	Fan Medium	Medium Fan Speed
G1	Fan Low	Low Fan Speed
Y2	Y2	Stage 2 Cooling
Y1	Y1	Stage 1 Cooling
W2	W2	Stage 2 Heating
W1	W1	Stage 1 Heating
G	G	Fan



**PAC-US444CN-1**

## WIRING THE CIRCUIT ENABLE

Each circuit requires an enable. The RenewAir system uses the cooling Stage 1 for LEV kit 1's A1 and A2 terminals, and if a second circuit is used, it uses cooling Stage 2. These are dry contact outputs and are wired to provide 24VAC when active.



**Wiring to Stage 1 (and Stage 2) LEV kit direct to expansion module**

### WIRING THE RENEWAIRE ALARM OUTPUT TO MITSUBISHI (OPTIONAL)


If the RenewAire unit is in alarm it will disable the VRF units by opening the contacts to A1 and A2. Additionally, the unit alarm may be sent to the Mitsubishi system if desired. In order for the VRF system to know if the RenewAire unit is in alarm, the main controller has a dry contact NO6 output that tells whether there is a major alarm and that can be wired in as shown, using the normally closed side to E1 and E2 on each LEV kit. (Do not use NO6 from the expansion module for this.) The wiring diagrams are shown at the end of the document.

### WIRING THE DEFROST INPUTS (OPTIONAL)


When either circuit is in defrost, the fans will shut down but the RenewAire system will hold the circuits in defrost ON. Any circuit that is not in defrost will be turned off. The wiring should coincide with the digital input setting as shown. These are dry contact inputs.

```

I/O CONFIGURATION
D19 Inputs Used For
ID1: VRF Defr CK1
ID2: VRF Defr CK2
Must be different!
    
```





Defrost wiring circuit 1 for ID1 is wired to the orange terminal block instead of the jumper



Defrost wiring circuit 2 for ID2 is wired to the grey terminal block


### WIRING THE ALARM SIGNAL FROM MITSUBISHI TO RENEWAIRE (OPTIONAL)

If there is an extra digital input available, it is advised to wire to the ID1 unit enable. The alarm signal will shut the unit off by opening the contact.




**Error contact from Mitsubishi if wiring to ID1 as DI on/off**

If there is no open digital input the input can be wired in series with the supply air damper end switch. A fan alarm will occur in this instance.




## WIRING THE HOT GAS REHEAT (OPTIONAL)


Mitsubishi recommends using a separate condensing unit for HGRH. To wire this, we use the U8 output of the controller in the B1/B2 analog input, and the cooling tempering to A1/A2. This feature also requires a cooling coil leaving air temperature sensor. DOAS units with factory-installed HGRH coils include this sensor. Other units will require an additional sensor. (P/N: 131318).



**Hot gas reheat (HGRH)**



**Wiring of the cooling coil leaving temperature (LAT) directly to the expansion module**



**HGRH 0–10 VDC signal to the LEV kit for the HGRH direct from expansion module**

## CONTROLLER SETTINGS

### UNIT CONFIGURATION

In Unit Configuration (password protected area), set the following settings:

```
UNIT CONFIGURATION
Unit Type: Premium
Bypass Damp: Disable
BP Type: Two-Position
Isolat Damp: Enable
Enable Heat: YES
Enable Cool: YES
Enable Frost. Cntl NO
```

Make sure the Enable Heat and Enable Cool are set to Yes.

```
UNIT CONFIGURATION
CLG TYPE:VRF
HTG TYPE:VRF

NOTE: CA Sensor is
required in the duct
downstream. PN 131318
```

You can set the cooling and heating type here or the settings are also in the Control Settings.

- ◆ Set cooling to VRF
- ◆ Set heating to VRF or VRF&Mod if using auxiliary heat

```
UNIT CONFIGURATION
En Mod HGRH: YES
En 2Pos HGRH: NO
If HGRH enabled, go to
I/O Conf19 and set
Dehum changeover mode
and assign LAT sensor
to a free input.
```

If you have HGRH, enable the modulating HGRH here.

## I/O CONFIGURATION

Set the I/O configuration to match your application (password protected area):

```
I/O CONFIGURATION
D19 Inputs Used For
ID1: VRF Defr CK1
ID2: VRF Defr CK2
Must be different!
```

In I/O Configuration, set the ID1 and ID2 to match the connected inputs.

```
I/O CONFIGURATION
U5 Remote Sensor
Coil LAT
```

If you have HGRH, make sure the coil leaving temperature is set for Coil LAT on U5.

```
I/O CONFIGURATION
Dehumidification
Changeover Selection
Return Air Value

Choose Outdoor Air for
applications w/19 amts
of Outdoor Air/changes
```

Enable the Dehumidification here if you desire to have a lower temperature for dehumidification. If you have HGRH, make sure you enable this selection. You can change over based on return air or outdoor air.

Other settings may be required if using the CO2 sensors, etc. Please consult the control manual for related information.

## CONTROL SETTINGS

In Control Settings (after the fan settings), set the following settings:

```
CONTROL SETTINGS
HEATING
Type VRF
Setpoint Adjust
Control Supply Air
OA Lockout Above
65.0°F
```

For the Heating selection, set:

- ◆ Type VRF or VRF&Mod
- ◆ Setpoint Adjust (via setting)
- ◆ Control Supply Air
- ◆ OA lockout temp for heating—set to OA temperature above which heating will be locked out

```
CONTROL SETTINGS
COOLING
Type VRF
SetP Adjust
Control Supply Air
OA Lockout Below
70.0°F
```

For the Cooling selection, set:

- ◆ Type VRF
- ◆ Setpoint Adjust (via setting)
- ◆ Control Supply Air
- ◆ OA lockout temp for cooling—set to OA temperature below which heating will be locked out

```
CONTROL SETTINGS
VRF Output Type
Mits VRF Type 1 OA
TWO STAGE ? : YES
```

Set type of integration: Mitsubishi Type 1 or Standard Capacity, and select whether the unit will have one or two stages.

```
CONTROL SETTINGS
VRF SETTINGS
Contact Open Heat
Aout Min 0.0%
Aout Max 100.0%
Cooling Min Aout Min
```

Select whether you want the tempering mode contact to be open for heat or for cool.

Leave the other settings as shown.

```
CONTROL SETTINGS
HEATING
VRF - Adjustable
Setpoint 64.0°F
Kp 1.0
Ti 30
```

This is the discharge air setpoint for heating.

Kp and Ti are used to tune the heating control loop that is used for capacity control and also for two-stage heating.

## CONTROL SETTINGS (CONT.)

In Control Settings (after the fan settings), set the following settings:

```

CONTROL SETTINGS
HEATING
URF - Adjustable
Setpoint 64.0°F
KP 1.0
Ti 30
URF Lowest OA 19.9°F
URF Mod HW Vlv? NO
    
```

If you have auxiliary heat, you will also have a setting for VRF lowest OA, which will be the temperature at which the auxiliary heat takes over. If the auxiliary heat is a 10–0V modulating hot water valve, the last setting should be Yes.

```

CONTROL SETTINGS
COOLING
URF Adj
Setpoint 75.2°F
KP 1.0
Ti 30
    
```

This is the discharge air setpoint for cooling.

Kp and Ti are used to tune the cooling control loop that is used for Capacity control and also for two-stage cooling.

```

CONTROL SETTINGS
URF
Single Stage
Hysteresis 3.6°F
Min ON Time 300s
Min Off Time 300s
    
```

One-Stage Only

```

CONTROL SETTINGS
Two Circuit
Stage 1 Stage 2
ON: 3% 51%
OFF: 0% 45%
Req 1 on for 2 on? YES
    
```

Two-Stage Only:

- ◆ Based on demand, tell when each stage will turn on and off.
- ◆ Is circuit 1 required for circuit 2 to run?

```

CONTROL SETTINGS
Two Circuit Timings
Min On Time: 30min
Min Off Time: 10min
Interstg Dly: 15min
    
```

Two-Stage Only:

- ◆ Minimum stage on/off and interstage delay.

# APPLICATION NOTES



## MODE OF OPERATION

For heating and cooling, the mode is determined by the outdoor air temperature.

For dehumidification, the mode is determined by the outdoor air or return air dewpoint. The unit will only dehumidify if the outdoor air temperature is above the cooling lockout setpoint.

The order shown is the priority.

- 1** Heat Lockout OA Temp
- 2** Cool Lockout OA Temp
- 3** Dehumidification Changeover (Based on OA or RA)




## SETTING STAGING PARAMETERS


There are staging parameters depending upon whether the unit is one or two stages.

### ONE STAGE PARAMETERS

The main parameter is the hysteresis, which has the following effect on control.




Hysteresis behavior in cooling




Hysteresis behavior in heating

### TWO STAGE PARAMETERS

The main parameters are the proportional band, Stage 1 on, and Stage 2 on, which has the following effect on control. Stage 1 goes off at setpoint. Stage 2 goes off at the Stage 1 on point. The off values may be adjusted in the I/O configuration.




Parameters behavior in cooling




Parameters behavior in heating


## MONITORING IN UNIT STATUS



If using Type 1 control, the first screen will show the information for the 0–10 VDC output.




This screen shows the acting setpoint and staging information.




This screen will show any stages that are on or off due to timing. (E.g., if a stage is on due to minimum on time.)

# WIRING DIAGRAMS

## ONE CIRCUIT VRF WIRING



## TWO CIRCUIT VRF WIRING



## HGRH VRF WIRING

