



CURB LE5X



TOP VIEW



TOP VIEW

ABBREVIATIONS

EA: Exhaust Air to outside
 OA: Outside Air intake
 RA: Room Air to be exhausted
 FA: Fresh Air to inside
 RTV: Rooftop Vertical RA & FA
 RTR: Rooftop Vertical RA Only

INSTALLATION ORIENTATION


Unit must be installed in orientation shown.

NOTE:


1. UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE ROUNDED TO THE NEAREST EIGHTH OF AN INCH.

2. SPECIFICATIONS MAY BE SUBJECT TO CHANGE WITHOUT NOTICE.


CURB CROSS-SECTION B-B (TYP.)




SECTION B-B



LEFT VIEW



FRONT VIEW



RIGHT VIEW

Model: LE5X RTV/RTR
 Drawing Type: Unit Dimension
 Version: APR26

